




209


Product Description: Self-Propelled Unit
Model Number: LMX7600SP
Service Item Number: 2853961001S01
Version: A
Issue Date: 2026/02/01





Product Description: Handle Assembly
Model Number: LMX7600SP
Service Item Number: 2852565003S01
Version: A
Issue Date: 2026/02/01

210



Service Part List_LMX7600SP_Version A

No.	Product Model#	Part Number	Description	Qty
1	LMX7600SP	5610893001	Hexalobular Socket Pan Head Flange Tapping Screw	2
2	LMX7600SP	2853426001	Battery Box Cover Assembly	1
3	LMX7600SP	2853404001	Front Cover Assembly	1
4	LMX7600SP	3137022001	LED Cover	1
5	LMX7600SP	3700367001	Cord Anchorage	4
6	LMX7600SP	5610294001	Tapping Screw	4
7	LMX7600SP	2854216001	LED Assembly	1
8,210-2	LMX7600SP	5620377003	Hexagon Socket Screw	25
9	LMX7600SP	5610291003	Tapping Screw	75
10	LMX7600SP	3126760001	Release Button	2
11	LMX7600SP	3131425001	Support Base	2
12	LMX7600SP	5620157006	Hexagon Socket Screw	8
13	LMX7600SP	3126772001	Sliding Block	2
14	LMX7600SP	3660303002	Spring	2
15	LMX7600SP	3131427001	Sliding Block	2
16	LMX7600SP	3403634001	Connecting Seat Wire Assembly	1
17	LMX7600SP	3660979001	Compression Spring	2
18	LMX7600SP	3131426001	Supporting Structure	2
19	LMX7600SP	2852157001	Battery Box Assembly	1
20	LMX7600SP	5640353003	Flange Bolt-Large Series	4
21	LMX7600SP	3700155002	Washer	5
22	LMX7600SP	2852822001	Bumper Assembly	1
23	LMX7600SP	2853066001	Bumper Assembly	1
24	LMX7600SP	5610376002	Hexagon Socket Screw	2
25	LMX7600SP	3710431001	Fixing Board	2
26	LMX7600SP	3710418001	Right Support Tube	1
27	LMX7600SP	3710420001	Left Support Tube	1
28	LMX7600SP	3710419001	Right Support Tube	1
29	LMX7600SP	3710421001	Left Support Tube	1
30,210-6	LMX7600SP	5640217004	Bolt and Washer Set	10
31	LMX7600SP	2730470001	DC Motor	2
32	LMX7600SP	2246575002	Brand label	1
33	LMX7600SP	2246575001	Brand label	1
34	LMX7600SP	2246576001	Specific label	1
35	LMX7600SP	5650012007	Plain Washer	4
36	LMX7600SP	3137298001	Knob	1
37	LMX7600SP	3668169001	Torsion Spring	1

No.	Product Model#	Part Number	Description	Qty
38	LMX7600SP	2246568001	Specific label	1
39	LMX7600SP	5620358002	Flange Screw	4
40	LMX7600SP	2852586001	Front Wheel Assembly	2
41	LMX7600SP	3705216001	Mounting Plate	2
42	LMX7600SP	5620480002	Screw	4
43	LMX7600SP	3137139001	Right Fairing	1
44	LMX7600SP	3137140001	Left Fairing	1
45,209-9	LMX7600SP	3137345001	Height Adjusting Lever	2
46	LMX7600SP	5650453001	Wave Washer	2
47	LMX7600SP	3300081001	Fan	2
48	LMX7600SP	3710454001	Blade	2
49	LMX7600SP	3137137001	Rear Enclosure	1
50	LMX7600SP	5650510001	Washer	2
51	LMX7600SP	5640226002	Flange Bolt	2
52	LMX7600SP	3706813001	Cord Anchorage	1
53	LMX7600SP	3668170001	Tension Spring	1
54	LMX7600SP	3706726001	Spring Seat	1
55	LMX7600SP	2831845001	Hall Electric Assembly	1
56	LMX7600SP	2832699001	Right Main Electric Assembly	1
57	LMX7600SP	2832700001	BMS Electric Assembly	1
58	LMX7600SP	2832714001	Self-propelled Control Electric Assembly	1
59	LMX7600SP	2832058002	Power Control Electric Assembly	1
60	LMX7600SP	2832701001	Left Main Electric Assembly	1
61	LMX7600SP	5690748001	Felt Ring	2
62	LMX7600SP	3700334001	Wave Washer	2
63	LMX7600SP	3137142001	Guide Block	1
64	LMX7600SP	3137141001	Adjusting Block	1
65	LMX7600SP	2246563001	Specific label	1
66	LMX7600SP	2243529020	Warning label	2
67	LMX7600SP	5690762001	Rubber Ring	3
68	LMX7600SP	5610224002	Hexagon Lobuar Screw	7
69	LMX7600SP	3710403001	Support Plate	1
70	LMX7600SP	5610868001	Hexagon Socket Button Head Screw	4
71	LMX7600SP	3710474001	Depth Stop Plate	1
72	LMX7600SP	5611490001	Hexalobular Socket Pan Head Tapping Screw	6
73	LMX7600SP	3710478001	Depth Stop Plate	1
74	LMX7600SP	3710460001	Protecting Cover Plate	1
75	LMX7600SP	5611489001	Hexalobular Socket Tapping Screw	8

No.	Product Model#	Part Number	Description	Qty
76	LMX7600SP	3710459001	Protecting Cover Plate	1
77	LMX7600SP	2852539001	Right Supporting Plate Assembly	1
78,210-16	LMX7600SP	5630571001	Prevailing Torque Type All-metal Hexagon Nut	8
79	LMX7600SP	3134881001	Bottom Board	2
80	LMX7600SP	3135113001	Turn Round Support	3
81	LMX7600SP	3137287001	Trail Shield	1
82	LMX7600SP	2852540001	Left Supporting Plate Assembly	1
83	LMX7600SP	5611488001	Hexagon Washer Head Tapping Screw	6
84	LMX7600SP	3423561001	Turntable	2
85,210-18	LMX7600SP	5611201001	Hexalobular Socket Screw	8
86	LMX7600SP	5660139002	E Ring	1
87	LMX7600SP	5611516001	Hexagon Socket Button Head Screw	6
89	LMX7600SP	3668161001	Torsion Spring	1
90	LMX7600SP	5670894001	Clevis Pin with Head	1
91	LMX7600SP	2246577001	Warning label	1
92	LMX7600SP	3137013001	Service Cover	1
93	LMX7600SP	3403524001	Lock Button	2
94	LMX7600SP	3137023001	Protecting Sleeve	1
95	LMX7600SP	2852830001	Side Discharge Chute Assembly	1
96	LMX7600SP	3137133001	Mulch Plug	1
97	LMX7600SP	5640212003	Bolt	2
98	LMX7600SP	3800282001	Grass Catcher	1
201	LMX7600SP	3137082002	Right Cover	1
202	LMX7600SP	3137081002	Left Cover	1
203	LMX7600SP	3137080002	Top Cover	1
204	LMX7600SP	2852835002	Cover Plate Assembly	1
205	LMX7600SP	2852891001	Front Axle Set	1
206	LMX7600SP	2852816003	Deck Unit	1
207	LMX7600SP	2852600001	Rear Wheel Assembly	2
208	LMX7600SP	2853594001	Rear Cover Assembly	1
209	LMX7600SP	2853961001	Self-Propelled Unit	1
209-1,210-10	LMX7600SP	5620011011	Hexagon Socket Screw	6
209-2	LMX7600SP	3137245001	Protective Cover	2
209-3	LMX7600SP	5660246001	"E" Ring	2
209-4	LMX7600SP	3570481001	Clutch Gear	1
209-5	LMX7600SP	5670186002	Pin	2
209-6	LMX7600SP	5690632001	Dust Seal	2
209-7	LMX7600SP	5610342001	Thread Forming Screw	15

No.	Product Model#	Part Number	Description	Qty
209-8	LMX7600SP	3137182001	Support	1
209-10	LMX7600SP	3710562002	Upper Support	1
209-11	LMX7600SP	5650004008	Plain Washer	1
209-12	LMX7600SP	3570480001	Clutch Gear	1
209-13	LMX7600SP	2730468001	DC Motor	1
209-14	LMX7600SP	3134884001	Rubber Block	1
210	LMX7600SP	2852565003	Handle Assembly	1
210-1	LMX7600SP	2850686001	Cable Set	1
210-3	LMX7600SP	3900755001	Decorative Cover Assembly	1
210-4	LMX7600SP	3137020001	Clamp Block	1
210-5	LMX7600SP	2246061001	Specific label	1
210-7	LMX7600SP	2246631001	Warning label	1
210-8	LMX7600SP	2832673001	Bluetooth Electric Assembly	1
210-9	LMX7600SP	3650404001	Control Handle	1
210-11	LMX7600SP	3650337001	Self-propelled Control Handle	1
210-12	LMX7600SP	3900756001	Decorative Cover Assembly	1
210-13	LMX7600SP	3137986001	Fixing Block	1
210-14	LMX7600SP	3423564001	Turntable	1
210-15	LMX7600SP	5620642001	Screw	1
210-17	LMX7600SP	3709136001	Rubber Gasket	2
210-401	LMX7600SP	2853499001	Switch Box Assembly	1
210-402	LMX7600SP	2853332001	Turntable Assembly	1
211	LMX7600SP	2852827001	Frame Assembly	1